

HOW TO KEEP YOUR SNOWBLOWER FROM GETTING CLOGGED:

- First, always wear protective gloves and eyewear.
- Make sure that the snowblower's ignition is off and that the surface is dry.
- The surface area of the snowblower's auger, blade and/or chute may become rough after repeated use, causing the snow to stick and clog the blower.
- For a long-term solution to this clogging issue, apply liquid car wax to all surfaces of the auger, blade and chute using a soft cloth. Take a second cloth to remove any excess wax and buff area.
- For a short-term solution, apply WD-40 to the auger, blade and chute each time you use the snowblower.

Have any questions for Jack Dever? Email him at jackdever@sbcglobal.net